


16:05 Room 20.5°C	16:06 Exterior 18.5°C	Outside temp. 18.5°C	Room temperature 20.5°C
19.03.2004 16:07 Room 20.5°C	19.03.2004 16:07 Exterior 18.5°C	19.03.2004 16:07 Room 20.5°C	19.03.2004 16:07 Room 20.5°C


** One of these eight additional basic display types is available as an alternative.



B.IQ push-button with room temperature regulation and display

The following menu list will help you to change the operating mode, to set the temperatures, to program the various functions such as the timer and the week timer and to specify the default settings.

You can find more information in the Internet at www.berker.com



***see on left Analog sequence:
The two week timers (with 14 switching times each) are programmed in the same sequence as the room temperature timer. The switching status or the values specified in the software are changed in the last stage here instead of the operating mode.

Changing the days of the week:
Mo-Fr, Sa-Su, Mo-Su, Mo, ... Su

Changing the point in time: press: / min. hold: / 5 min.

- Comfort
- Standby
- Night

Valid for the following order numbers:
 3gang push-button RTR: 75 66 359x
 4gang push-button RTR: 75 66 459x
 5gang push-button RTR: 75 66 559x